




CABINET PARTS

For Models: LEQ8857JQ0, LEQ8857JT0
(Designer White) (Biscuit)

ELECTRIC DRYER



Literature Parts

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Models: LEQ8857JQ0, LEQ8857JT0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	LIT3397618	Literature Parts Instructions, Installation	17	279318	Terminal, Tinned & Brass (3) (Includes Illus. 39)	37		Handle, Door
	LIT8314844	Use & Care Guide					3405184	White
	LIT3977704	Label, Wiring Diagram	18		Cabinet (Includes Illus. Nos. 5,7,15,41 And 57.)		3405189	Biscuit
2	343641	Screw, 10–16 x 1/2		3399585	White	38	3406129	Seal & Bearing Assembly
3	693995	Screw, Hex–Head		3399595	Biscuit	39	279393	Terminal Block Kit (For Terminal Block)
5	3396795	Cover, Block	19	98234	Clip, Ground	40	697776	Screw, 10–32 x 5/8
6		Plug, Strike Hole	20	690363	Lock, Front Top (2)	41	3397659	Block, Terminal
	3403630	White	21		Front Panel Assembly	51	238088	Hinge, Top (2)
	3403632	Biscuit		3403444	White	53	3394332	Idler & Slide Assembly
7	3396805	Panel, Rear		8282481	Biscuit	56	341241	Belt, Drive
10	3406107	Door Switch Assembly	23	685203	Clip, Felt Pad (3)	57	348780	Base, Motor
11	697773	Screw, 6–20 x 7/8	24	690081	Catch, Door Assembly	58	3400500	Bolt, 5/16–18 x 3/4
12		Plug, Hinge Hole (4)	27	342055	Screw, 8–18 x 1/2	59	3394341	Pulley, 60 Hz.
	3404413	White	28	3405514	Hinge, Door	62	3976707	Motor Assembly 60 Hz.
	3404415	Biscuit	33	3403431	Strike, Door	63	660658	Clamp, Motor
15	3394083	Clip, Front Panel (2)	35	3402341	Door, Rear	64	3404162	Clamp, Motor (W/Shield)
16	3392100	Foot, Dryer	36		Door, Front	67	3405246	Seal, Door
	279810	Foot–Optional (Extended Length Package of 2) (Not Included)		3402335	White	87	3393008	Screw, 10–16 x 1/2
				3402337	Biscuit			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: LEQ8857JQ0, LEQ8857JT0
(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: LEQ8857JQ0, LEQ8857JT0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8274261	Panel, Rear Console	12	691193	Hinge, R.H.	29	3390646	Screw, Mounting (8-18 x 5/16)
2	3401684	Wire, Jumper (Black)		691194	Hinge, L.H.	30	357213	Nut, Push-In (2)
3	693995	Screw, Hex Head	13	688983	Screw, 8-18 x 5/8	31	8283282	Harness, Wiring
4		Cap, End (L.H.)	14	94614	Terminal	32	3396030	Wire, Jumper (Temperature)
	8271365	White	15	3395683	Connector (Motor)	39	3398095	Relay, Push-To-Start
	8271368	Biscuit	16		Top	48		Timer Knob Assembly
5	3405154	Switch, Finish Guard		8271390	White		8312687	White
6	388326	Screw, Console		8271392	Biscuit		8271404	Biscuit
7	694419	Buzzer, Mini	17		Knob, Control (2)	50	3936144	Connector
8		Cap, End (R.H.)		8271339	White	51	3390537	Control, Electronic
	8271359	White		8271348	Biscuit	52	3391885	Connector, Edge
	8271362	Biscuit	18	3394427	Clip-Harness	53	8271418	Bracket, Control
9	3977426	Switch, Temperature	19	297535	Bumper, Lint Lid	54		Panel, Control
10	349639	Screen, Lint	20	3401144	Connector, (PTS Relay)		3977827	White
11		Cover, Lint	21	3406725	Timer, 60 Hz.		3977828	Biscuit
		Screen	22	3347243	Connector 6-Circuit	55	343641	Screw, 10-16 x 1/2
	8283378	White	23	3397269	Connector, Timer			
	8283380	Biscuit	24	3400859	Screw, Grounding			

OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, TOUCH-UP (1/2oz.)

72017 White
4392899 Biscuit

PAINT, PRESSURIZED SPRAY (12 oz.)

350930 White
4392901 Biscuit
350938 Primer, Gray

PAINT, BULK (1 qt.)

799344 White (Uncut)
4392900 Biscuit(Uncut)

Following May Be Purchased


DO-IT-YOURSELF REPAIR MANUALS

LIT677818 Dryer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: LEQ8857JQ0, LEQ8857JT0
(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: LEQ8857JQ0, LEQ8857JT0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly	12	3398161	Clip	33	3406124	Bulb
2	487909	Screw, 8-18 x 1/2	13	343641	Screw, 10-16 x 1/2	34	3402841	Lens, Drum Light
3	3388703	Washer-Support	14	3397566	Box, Heater	41	690997	Ring, Tri
4	347139	Seal, Lint Chute	15	3399693	Thermostat, 250°F (121.1°C)	42	3399506	Shaft, L.H.
5	90767	Screw, 8-18 x 3/8	16	3977373	Bracket, Drum Light	43	3399507	Shaft, R.H.
6	696302	Shield, Exhaust	17	3403585	Element, Heater	44	3397588	Roller, Support
7	3392519	Thermal Fuse	18	3977358	Drum Hole Plug	46	348197	Washer, Support
8	3977706	Thermostat, Internal-Bias	19	279457	Wire Kit, Terminal (For Heater Element Wiring Harness Repair)	47	3359452	Nut, 3/8-16
9	3977393	Thermal, Cut-Off (Hi-Limit Thermostat Illus. No.15 Included)	20	489463	Screw, 8-18 x 5/8	48	3403414	Bulkhead
10	694089	Wheel, Blower (Includes Illus. No. 22)	22	3394196	Seal, Blower	49	3403634	Socket Assembly
11	3405016	Housing, Blower	30	3976479	Pad, Sensor	62	692526	Ring, Bearing (2)
						63	97787	Screw, 11-16 x 3/4
						66	3406130	Seal, Rear Drum
						67	695587	Drum Assembly
						68	692490	Baffle, Drum (2)
						69	3976434	Bracket, Support
						70	90296	Clip
						71	3403636	Baffle, Drum (1)
						73	339956	Seal

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST